



INSTALLATION INSTRUCTIONS

You will need to insert a length of timber or aluminium into the top and bottom pocket. 40mm x 25mm is recommended. Cut timber 10mm shorter than the width of the blind. Once in the pocket hold in place with a screw and washer. Bottom picket has the first eyelet directly above it.

Fasten the top roll up straps in place on the top pocket approx 300mm in from each end. Strap folded in half with 2 dees on the front side and the long strap on the back.

Screw blind in at top normal screw length you will need is 75mm but this varies depending on what you are screwing into and what you have used in the top pocket.

Roll the blind down and attach cputs to your posts lining up with the eyelets in the sides of the blind.

Any questions please email info@covaflex.co.nz or call 0800 268 235 our customer service team will be happy to assist you

CARE INSTRUCTIONS

These instructions will maintain the appearance and extend the functional life of your blind

Do Not

Dryclean

Iron

Use a stiff brush, vigorous rubbing or tumble dry

Use abrasive cleaners

Allow contact with petrol, acetone or other similar products

General Care

Vacuum regularly using low suction to remove loose dirt.

Clean regularly with hot or warm soapy water and a soft brush, Or lightly sponge down with warm water.

Allow to dry thoroughly before storage.

Spot Cleaning/Special Treatments

Treat stains as soon as possible.

Mildew may be removed by wiping with a cold solution of sodium having 4% chlorine, in the proportion of 1 part to 4 of water. Rinse thoroughly with cold water.

Grease spots may be removed carefully by rubbing lightly with a soft cloth and some ethanol (ethyl alcohol)



INSTALLATION INSTRUCTIONS

You will need to insert a length of timber or aluminium into the top and bottom pocket. 40mm x 25mm is recommended. Cut timber 10mm shorter than the width of the blind. Once in the pocket hold in place with a screw and washer. Bottom picket has the first eyelet directly above it.

Fasten the top roll up straps in place on the top pocket approx 300mm in from each end. Strap folded in half with 2 dees on the front side and the long strap on the back.

Screw blind in at top normal screw length you will need is 75mm but this varies depending on what you are screwing into and what you have used in the top pocket.

Roll the blind down and attach cputs to your posts lining up with the eyelets in the sides of the blind.

Any questions please email info@covaflex.co.nz or call 0800 268 235 our customer service team will be happy to assist you

CARE INSTRUCTIONS

These instructions will maintain the appearance and extend the functional life of your blind

Do Not

Dryclean

Iron

Use a stiff brush, vigorous rubbing or tumble dry

Use abrasive cleaners

Allow contact with petrol, acetone or other similar products

General Care

Vacuum regularly using low suction to remove loose dirt.

Clean regularly with hot or warm soapy water and a soft brush, Or lightly sponge down with warm water.

Allow to dry thoroughly before storage.

Spot Cleaning/Special Treatments

Treat stains as soon as possible.

Mildew may be removed by wiping with a cold solution of sodium having 4% chlorine, in the proportion of 1 part to 4 of water. Rinse thoroughly with cold water.

Grease spots may be removed carefully by rubbing lightly with a soft cloth and some ethanol (ethyl alcohol)